

How to light the Portable Firepit & BBQ

54cm Portable Firepit & BBQ



Step 1:

Make sure the assembly instructions have been followed correctly.

Step 2:

Set up in a suitable position, on a firm level surface away from areas likely to catch fire. The base will get hot so ensure it is standing on a appropriate surface which will not be damaged by fire. Use logs or Bar-Be-Quick Firepit/Chimenea Fuel or Lighting products.

Step 3: Starting the fire

Add 3-4 sheets of scrunched up newspaper onto the firegrate grill and add a generous pile of kindling pieces. You can also use our lighting gel to assist lighting. See our website for more details - www.barbequick.com

Step 4: Lighting the fire

Use Bar-Be-Quick long safety matches or a gas lighter to light the newspaper and kindling or lighting gel.

Step 5: Add more wood to keep the fire burning

Once the fire has caught, add more fuel to keep the fire going and generate heat.

Step 6: If using the firepits cooking grill (included)

If you are to cook any food on this Firepit, only use Bar-Be-Quick charcoal, following the instructions on the charcoal bag. Do not use any wood to directly cook over.

Simple assembly instructions - Please keep for future reference


Before you start assembling your Firepit here are some important safety warnings



NOTE! Missing parts Tel 01282 478200 Email sales@rectella.com

WARNINGS

1. This product generates extreme heat therefore great care must be taken with using, handling and with safe disposal.
2. Do not use barbecue/firepit in a confined and/ or habitable space e.g. houses, tents, caravans, motor homes, boats or other confined space. Danger of carbon monoxide poisoning fatality.
3. Do not use in prohibited areas or areas which prohibit open fires.
4. Never use petrol, methylated spirits or any other similar volatile fuels to ignite or re-ignite barbecues or fires.
5. Never place your barbecue on, or near, anything liable to be damaged by heat or flare up or from hot fat which may spit during cooking.
6. Due to the potential risks involved with barbecuing, it is recommended that an adult not consuming alcohol is in control of the barbecue and that first aid and other emergency provisions such as fire extinguishers, are at hand.
7. Always keep children and pets away from the barbecue area.
8. Never leave a lit barbecue unattended.
9. Never handle the barbecue while in use as it soon becomes very hot.
10. To prevent food poisoning, always ensure that food is completely defrosted before cooking commences and that it is always cooked thoroughly.
11. After use, extinguish completely and allow to go cold before handling or moving.
12. Remember the area beneath and around your barbecue will become extremely hot and may remain so for some time after use.



NOTE: This is the current warning symbol for Carbon Monoxide poisoning. Using this product in a confined space will create fumes which can kill. Use only in open areas with unrestricted airflow

Care and Maintenance

1. To make it easier to clean your Firepit/BBQ after use, line the firebowl with aluminium cooking foil, shiny side up. Remember to leave ventilation holes clear by piercing foil where necessary. This process will lengthen the life of your Firepit/BBQ and reflect the heat more efficiently onto the food.
2. Charcoal is available in lumpwood form (large irregular pieces) and briquettes (uniform pieces). As a guide lumpwood works best for quick cook foods such as sausages and burgers, whilst briquettes are more suitable for slow cooking, smoking or roasting as they burn longer and hotter.
3. Do not use more than 2kg of charcoal with this Firepit/BBQ. It is not advisable to completely fill the firebowl as the barbecue may become too hot to cook successfully.
4. If the fire flares up due to dripping fat, douse the flames lightly with a fine water spray.
5. When you have finished cooking never pour cold water over the coals to extinguish, as this may damage your barbecue. Use sand, old cinders or a fine water spray.
6. To clean your barbecue soak the grills and tools in hot soapy water as soon as possible after use. Dry thoroughly and store in a dry place. Do not leave your BBQ outside unprotected.



54cm Portable Firepit & BBQ- Components



REQUIRED TOOLS (NOT SUPPLIED):

Wrench



Phillips Screw Driver



| PART NUMBER | QUANTITY | DESCRIPTION | PICTURE |
|-------------|----------|-------------|---------|
| A | 1 | Fire Tool | |
| B | 1 | Fire Screen | |
| C | 1 | Fire Bowl | |
| D | 1 | Fire Grate | |
| E | 3 | Legs | |

SUPPLIED PARTS & HARDWARE LIST:

| PART NUMBER | QUANTITY | DESCRIPTION | PICTURE |
|-------------|----------|--------------------------------|---------|
| F | 1x | Fire Screen Assembly M6 | |
| G | 3x | Leg - Fire bowl Assembly M5x10 | |

TOOLS NEEDED: 8mm OPEN END OR ADJUSTABLE SPANNER & CROSS HEAD SCREWDRIVER.

PRE-ASSEMBLY CHECK

To ensure fast and easy assembly, follow the instructions below in their proper sequence. Check all parts carefully and compare them to the parts listing. Report any missing parts to the helpline listed on the front of these instructions.

1 Stage One - Fitting the legs
Attach the 3 legs with 2 nuts and bolts provided for each, making sure they are tight. (Maybe pre assembled).



2 Stage Two - Open and lock legs
Pull on the locking pin and unfold each leg till you hear a click, checking they are all secure. They will also lock when re-closed. Helpful when fitting into the carry bag (included).



3 Stage Two - Add grills
Place fire grate grill centrally in the bowl of the firepit. This fire grate grill helps with airflow when burning and should always be used. Don't just place logs directly in the bowl. We also include a top grill for cooking on.



4 Stage Four - Grill Cover
Place handle for the grill cover through hole and secure with a nut. Remember to use the "fire tool" to place and remove this cover when the firepit is in use.

You're now ready to light your Firepit.

