



Assembly


Slot the thin rods into the holes near the feet on both sides at 'A' 'B' 'C' 'D'



Instructions

Please follow these instructions carefully before lighting

Party Instant BBQ



Make sure that all three points are grounded

IMPORTANT

If the frame rocks apply pressure at points 'A' and 'B' to ground all three points. Once stabilized tighten ALL wing nuts to secure position.


Place the party Instant BBQ into the frame making sure it is fully supported along each cross bar at section 'C' and 'D'

Standard Instant BBQ

Place the standard Instant BBQ into the frame from above.

IMPORTANT

The Instant BBQ should rest on the Frame at points 'A' and 'B'. If they do not please adjust these sections by rotating them to secure the Instant BBQ. Once stabilized tighten ALL wing nuts to secure position.



www.barbequick.com

IMPORTANT: Do not attempt to remove the Instant BBQ until all the coals have been extinguished and has cooled.

Made in China for:

© Rectella International Limited. 2014
 Bar-Be-Quick[®] is a registered trademark of Rectella International Limited. Bancroft Road, Burnley, Lancashire. BB10 2TP

This product is protected by the intellectual property rights belonging to Rectella International Limited which protect the design on the product and the packaging in which it is sold.

BQ2693-1a